



Cut-out drill guide above. Fold along dashed line (90 degrees). Place guide vertically along door jamb. Mark/drill three small holes using pilot bit. Using 1" spade bit, drill center hole approximately 1/8" deep recess. Mount base plate. Trim grayed notch on template down to base plate depth. Continue mounting latch per instructions.